

PRODUCT USE GUIDE FOR HI-SHINE FURNITURE POLISH G10

Product Description

For use on furniture, varnished wood, plastics, metals and other hard surfaces.

Direction for Use

- Shake gently before using.
- Spray on to clean duster and apply to the surface to be polished.
- Polish immediately with a soft dry cloth.
- Do not allow to dry.
- Contains silicone oils therefore it is not recommended for use on antique polish.

Storage

- Store in cool conditions away from direct sources of heat
- Avoid extremes of temperature
- Do not allow to freeze
- Ensure the lid is tightly fitted after use
- Keep out of reach of children

Shelf Life

- Shelf life 24 months, if stored as recommended.
- Use within 6 months of opening.

Environmental

- Empty containers must not be burned because of explosion hazard. Dispose of waste and residues in accordance with local authority requirements.
- None of the components of this product are animal derived.



Cleenol Group Ltd

Beaumont Road, Banbury, Oxon, OX16 1RB. UK.
Tel: +44 (0) 1295 251721 Fax: +44 (0) 1295 269561
Email: sales@cleenol.co.uk
www.cleenol.co.uk



Certificate No. 316



Certificate No. E3539

**PRODUCT USE GUIDE FOR
HI-SHINE
FURNITURE POLISH
G10**

For further information please scan your QR Smart Reader here



Code Nos.

0521116 6x400ml

Data Sheet No. G10

Note: This product is only to be used for the purpose for which it was intended and in accordance with the specified instructions. This product should never be mixed with other chemical products and should be handled with care and stored carefully out of reach of children.



Cleenol Group Ltd

Beaumont Road, Banbury, Oxon, OX16 1RB. UK.
Tel: +44 (0) 1295 251721 Fax: +44 (0) 1295 269561
Email: sales@cleenol.co.uk
www.cleenol.co.uk



Certificate No. 316



Certificate No. E3539